

AS01D and AS01DT off delay timer setup method:



No bridge: 10 minutes.
1-2 bridge: 20 minutes.
2-3 bridge: 30 minutes.

There is a bridge put on pin3, Customer can use it to bridge 1-2 or 2-3 to get 20 minutes or 30 minutes. If no bridge it's default value - 10 minutes.

Note: Power off the air switch before you change the bridge setting.

For AS01D, after you press the air switch button, the air switch turns on, after 10/20/30 minutes the air switch will turn off. If you want to turn off earlier than 10/20/30 minutes, press the air switch button which will turn off immediately.

For AS01DT, if the air switch is turned on using the air switch button, after 10/20/30 minutes the air switch will turn off. If you want to turn off earlier than 10/20/30 minutes, press the air switch button which will turn off immediately.

If the air switch AS01DT is on via the time clock, 10/20/30 minutes function will not operate.